

M&B/Europa Spec database upgrade

Disclaimer: Please note the use of these procedures is entirely the customer`s own risk. Please make sure you have familiarised yourself with all the steps before trying it. If you need assistance, please call me during office hours on 0638224941

1. Click on the <https://cpge.co.za/cpanel/wp-content/uploads/2019/05/DB.zip>
2. Open your **Downloads** folder in Windows
3. Find the **DB.zip** file and extract using suitable software
4. Place the new **DB folder** on the desktop for quick access
5. If the software was downloaded from another pc other than the Alignment system, then copy the extracted **DB folder** to a flash drive.
NB: please run a virus scanner on the flash drive before transferring on to the Aligner!
6. Close Alignment program
7. Right click **V3DAligner** icon on desktop
8. Select '**open file location**'. This will open the '**Aligner folder**'
9. Please find and Rename current '**DB**' folder to '**DBold**' or something similar. NB: This will allow you the ability to restore the old files in case the process goes wrong.
10. Open **flashdrive** in new window
11. Please do not follow the next step unless step 9 has been completed!
12. Copy '**DB**' folder from the flash drive and insert into '**Aligner**' folder . As per step 8
13. Close all windows and restart V3D Aligner program

Disclaimer: Please note the use of these procedures is entirely the customer`s own risk. Please make sure you have familiarised yourself with all the steps before trying it. If you need assistance, please call me during office hours on 0638224941